



## **Low Global Warming Fluids for Replacement of HFC-245fa and HFC-134a in ORC Applications**

**Gary Zyhowski\* and Andrew Brown†**

\*Honeywell, 20 Peabody St., Buffalo, NY USA 14210  
e-mail: [gary.zyhowski@honeywell.com](mailto:gary.zyhowski@honeywell.com)

**Honeywell**


# Agenda

Honeywell

---



- **Environmental**
- **Safety**
- **Properties**
- **Cycle Comparisons**
- **Conclusions**

# Honeywell – A History of Innovation



***Innovating To Enable Industry Compliance***

# Environmental / Safety



**Next Generation Offers Low GWP**

# Select Criteria for Replacement Molecules

---


Honeywell

- Environmental Properties
  - GWP
  - VOC
- Safety/Health
  - Flammability
  - Toxicity
- Performance
  - Thermodynamic Properties
  - Transport Properties
- Manufacturability
  - Chemistry
  - Cost
  - Raw Materials Cost/Availability
  - Materials Compatibility


***Numerous Factors Are Important for Replacement Selection***

# Environmental / Safety

## Flammability



## Volatile Organic Compound (VOC/ POCP)



**Next Generation Offers Solid Safety Performance**

# Environmental / Safety

FLAMMABLE	Burning Velocity, cm/s	LEL/UEL vol.% in air	Minimum Ignition Energy mJ @ 20C, 1 Atm.
• Pentane		• 1.4/7.6 <sup>2</sup>	• 0.78, 25°C, stoich. <sup>5</sup>
• Butane		• 1.8/8.4 <sup>2</sup>	• 0.26 @ 1atm, ~1.45 stoich. <sup>2</sup>
• Isobutane	• ~31.5 <sup>1</sup>	• 1.8/8.4 <sup>2</sup>	
• 365mfc		• 3.6/13.3 <sup>3</sup>	
• HFO-1234yf	• 1.5	• 6.2/12.3 <sup>4</sup>	• 5,000 – 10,000 <sup>6</sup>
• HFO-1234ze	• No flame propagation	• None at RT 5.7/11.3 (60°C) <sup>4</sup>	• No ignition <sup>7</sup> >61,000 <64,000 ( 54C, 1 Atm.) <sup>7</sup>
	<div style="border: 1px solid black; background-color: #800000; color: white; padding: 5px; text-align: center;">                     Low Rate of Pressure Rise                      HFO-1234yf                      HFO-1234ze                 </div>		<div style="border: 1px solid black; background-color: #800000; color: white; padding: 5px; text-align: center;">                     Difficult to ignite                      HFO-1234yf                      HFO-1234ze                 </div>

1 Engineering Journal of the University of Qatar, Vol. 14, 2001, p. 184

2 Us Dept. of the Interior Bureau of Mines Bulletin 680

3 Solvay MSDS

4 Honeywell

5 Combustion, Flames and Explosion of Gases, B. Lewis and Guenther von Elbe, Academic Press Inc., 1987, Orlando, FL 32887

6 Measured by DuPont, in-house method

7 Measured by Chilworth Technology

***HFO-1234yf & HFO-1234ze have lower flammability risk***

# Environmental / Safety

	Permissible Exposure Levels
• Pentane	600ppm (8-hr TLV-TWA, ACGIH) <sup>1</sup>
• Isopentane	600ppm (8-hr TLV-TWA, ACGIH) <sup>2</sup>
• Butane	1000ppm (8-hr TLV-TWA, ACGIH) <sup>2</sup>
• Isobutane	1000ppm (8-hr TLV-TWA, ACGIH) <sup>2</sup>
• Solkatherm SES36 (HFC-365mfc/PFPE)	
HFC-365mfc	1000ppm (Solvay limit) <sup>3</sup>
PFPE (1,1,2,3,3-hexafluoro, oxidized, polymerized)	none established for perfluoropolyether <sup>3</sup>
• HFC-245fa	400ppm (TWA, WEEL) <sup>4</sup>
• HFC-134a	1000ppm (TWA, WEEL) <sup>4</sup>
• HFO-1234yf	500ppm (TWA, WEEL) <sup>4</sup>
• HFO-1234ze	800ppm (TWA, WEEL) <sup>4</sup>
• Novec 7000	75ppm <sup>5</sup>
• Novec 649	150ppm <sup>5</sup>

1 ConocoPhillips MSDS  
2 Airgas MSDS  
3 Solvay Chemicals MSDS  
4 Honeywell MSDS  
5 3M MSDS


***HFC and HFO PELs can be met using typical control measures***



# HFO-1234yf & HFO-1234ze

## Physical Properties

	1234yf*	134a†	1234ze*
Boiling Point, $T_b$	-29° C	-26° C	-19° C
Critical Point, $T_c$	95° C	102° C	109° C
Molecular Weight	114.0	102.0	114.0
$P_{vap}$ , MPa (25° C)	0.677	0.665	0.498
$P_{vap}$ , MPa (80° C)	2.44	2.63	2.01
Liquid Density, kg/m <sup>3</sup> (25° C)	1094	1207	1163
Vapor Density, kg/m <sup>3</sup> (25° C)	37.6	32.4	26.4
Latent Heat, kJ/kg (10° C below $T_c$ )	66.6	76.3	73.1



**Higher critical temperature for HFO-1234ze**

# HFC-134a, HFO-1234yf, HFO-1234ze(E) ORC Cycle Comparison


Boiler Temp, °C	90.0	Boiler Temp, °C	110.0
Cond Temp, °C	13.0	Cond Temp, °C	13.0
Volume Flow Expander Exit, cm <sup>3</sup> /s	10.0	Volume Flow Expander Exit, cm <sup>3</sup> /s	10.0

Fluid	R134a	1234yf	1234ze(E)	R134a	1234yf	1234ze(E)
Thermal Efficiency	0.122	0.117	0.126	0.135	0.128	0.136
Net Work, J/gm	-26.4	-21.5	-26.2	-30.7	-25.5	-30.9
Net Work, J/s	-5.8	-5.4	-4.6	-6.5	-6.0	-5.1
Expander Exit Vapor Density, gm/cm <sup>3</sup>	0.022	0.025	0.017	0.021	0.024	0.016
Mass Flow, gm/s	0.22	0.25	0.17	0.21	0.24	0.16
Condenser Pressure, psia	66.4	68.8	49.5	66.4	68.8	49.5
Boiler Pressure, psia	430.0	412.7	359.0	565.2	531.1	445.1
Q Boiler, J/gm	216.6	184.0	209.0	227.8	199.2	226.8
Superheat in Boiler, °C	4.4	3.1	0.0	11.0	67.4	9.3

Calculations based on Honeywell data and internal proprietary models

**Comparable work and efficiency for HFO-1234ze vs. HFC-134a**

# HFC-134a, HFO-1234yf, HFO-1234ze(E) ORC Cycle Comparison (relative to 134a)



Thermodynamic Cycle Comparison - Adjustments to Operating Conditions

- HFO-1234yf, 110°C boiler temperature : Transcritical cycle optimized for best efficiency
- HFC-134a (90C, 110C boiler) , HFO-1234yf (90C boiler temperature), HFO-1234ze(E) (110C boiler)– boiler pressure lowered from saturation pressure to avoid 2-phase expansion



***Comparable work and efficiency for HFO-1234ze vs. HFC-134a***

# HFC-134a, HFO-1234yf, HFO-1234ze(E)

## Work Output and Efficiency vs. Boiler Temperature

Honeywell

Transition from subcritical to trans-critical



# HFC-134a, HFO-1234yf, HFO-1234ze(E)

## Turbine Impeller Diameter Comparison

Honeywell

	Boiler Temp, °C			Boiler Temp, °C		
	90.0			110.0		
Expander Sizing	R134a	1234yf	1234ze(E)	R134a	1234yf	1234ze(E)
Work Input, kJ/s	5000	5000	5000	5000	5000	5000
Pressure Ratio	6.48	6.00	7.26	8.51	7.72	9.00
Vol Flow, m <sup>3</sup> /s	1.05	1.08	1.37	1.03	1.06	1.34
Head, m	4025	3390	4031	4937	4212	4856
Impeller Speed rpm ( $n_s = 0.7$ )	18296	15803	16021	21451	18815	18598
Mach #	1.89	1.85	1.96	2.05	2.00	2.08
Impeller Diameter m ( $d_s = 4$ )	0.290	0.309	0.332	0.274	0.289	0.314

Turbine diameter  $D = d_s Q^{0.5} / H^{0.25}$  Assume a specific diameter of 4 (Balje Diagram)

Q is the volumetric flow rate (m<sup>3</sup>/s)

H is head (m<sup>2</sup>/s<sup>2</sup>)

$d_s$  is specific diameter (dimensionless)

Head is determined from the equation  $PR = [1 + (\gamma - 1) H / a^2]^{1/\gamma - 1}$

PR is the turbine pressure ratio (dimensionless)

$\gamma$  is the isentropic exponent (\*dimensionless)

\*for an ideal gas = heat capacity at constant pressure / heat capacity at constant volume,  $C_p / C_v$

a is the speed of sound in the particular working fluid (m/s)

Speed  $N = n_s H^{0.75} Q^{-0.5}$

$n_s$  is specific speed (dimensionless)


Joost Brasz and Patrick Lawless, Design, Analysis and Applications of Centrifugal Compressors, Short Course, Purdue University, July 10-11, 2004.

**HFO-1234ze bumps up dividing line between low boilers and RT boilers**

# Comparison of HFC-245fa & Honeywell's Replacement Candidate

## Physical Properties

	HFC-245fa*	HDR-14
Boiling Point, $T_b$	15° C	15° C < > 32° C (HCFC-141b)
Critical Point, $T_c$	154° C	Higher than HFC-245fa
$P_{vap}$ , MPa (25° C)	0.148	Lower than HFC-245fa
$P_{vap}$ , MPa (120° C)	1.93	Lower than HFC-245fa
Liquid Density, kg/m <sup>3</sup> (25° C)	1094	Higher than HFC-245fa
Vapor Density, kg/m <sup>3</sup> (25° C)	37.6	Lower than HFC-245fa
Latent Heat, kJ/kg (10° C below $T_c$ )	69.3	74.7



**Replacement candidate has higher boiling point &  $T_c$**

# HFC-245fa and Honeywell's Replacement Candidate

## ORC Cycle Comparison


Honeywell

Boiler Temp, °C	130.0
Cond Temp, °C	25.0
Volume Flow Expander Exit, cm <sup>3</sup> /s	10.0

Fluid	R-245fa	HDR-14
Thermal Efficiency	0.129	0.136
Efficiency, relative to R245fa	1.0	1.05
Net Work, J/gm	-35.8	-36.6
Work relative to R245fa	1.0	1.02
Net Work, J/s	-2.5	-2.2
Work relative to R245fa	1.0	0.88
Expander Exit Vapor Den, gm/cm <sup>3</sup>	0.007	0.006
Mass Flow, gm/s	0.07	0.06
Mass Flow, relative to R245fa	1.0	0.86
Q Boiler, J/gm	277.4	270.2
Q Boiler, relative to R245fa	1.0	0.97
Superheat in Boiler, °C	27.6	25.8

***Replacement candidate efficiency & work output favorable***

# Thermal Efficiency – A Broader Comparison Honeywell



***HDR-14 Thermodynamic Efficiencies Higher Than A Number of Known Working Fluids***



# HFC-245fa & Replacement Candidate


## ORC Turbine Impeller Diameter Comparison

Boiler Temp, °C	130.0
Cond Temp, °C	25.0
Volume Flow Expander Exit, cm <sup>3</sup> /s	10.0

Expander Sizing	HFC-245fa	HDR-14
Work Input, kJ/s	5000	5000
Pressure Ratio	9.00	9.00
Vol Flow, m <sup>3</sup> /s	2.57	3.11
Head, m	5000	5108
Impeller Speed rpm (ns = 0.7)	13734	12701
Mach #	2.08	2.08
Impeller Diameter m (ds = 4)	0.431	0.471

***HDDR-14 Requires Larger Wheel to Maintain Comparable Volumetric Flow at Expander Exit***

# ORC Turbine Impeller Sizing Comparison



# Conclusions

- **A low global warming replacement for HFC-245fa in ORC is on the near horizon.**
  - **HDR-14**
    - **Higher thermodynamic efficiency in ORC cycle**
    - **Comparable work output / unit mass circulated**
    - **Non-flammable**
- **Low global warming fluids are available to replace R-134a in ORC**
  - **HFO-1234ze(E)**
    - **Higher boiling point and critical temperature than R-134a**
    - **Comparable thermodynamic efficiency**
    - **Comparable work output / unit mass circulated**
- **Preliminary assessment of Honeywell replacements for 245fa and 134a in ORC is promising; additional testing required to substantiate findings**
- **GWP of HFO-1234yf, HFO-1234ze(E) and HDR-14 are comparable to hydrocarbons**

***Keep up to date. Visit [www.Honeywell-ORC.com](http://www.Honeywell-ORC.com)***

**THANK YOU!**

***Questions?***

**DISCLAIMER**

Although all statements and information contained herein are believed to be accurate and reliable, they are presented without guarantee or warranty of any kind, expressed or implied. Information provided herein does not relieve the user from the responsibility of carrying out its own tests and experiments, and the user assumes all risks and liability for use of the information and results obtained. Statements or suggestions concerning the use of materials and processes are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patents. The user should not assume that all toxicity data and safety measures are indicated herein or that other measures may not be required.